

CD-3112EX

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	25	CONNECT PLATE
2	CHUCK	26	MOTOR
3	TAPPING SCREW	27	CLIP
4	PRESS PLATE	28	BITS
5	FIXED BOARD	29	TAPPING SCREW
6	SPRING SHEET	32	RADIATOR
7	ADJUSTOR COVER	33	SCREW
8	INNER TOOTH RING	34	PULL LEVER
9	SPRING	35	SPEED REGULATOR
10	CIRCLIP	36	CONNECT BRACKET
11	WASHER	37	TAPPING SCREW
12	STEEL BALL	38	HOUSING OF BATTERY PACK
13	WASHER	39	BATTERY PACK BRACKET
14	STEEL BALL	40	STEEL BRACKET
15	GEAR BOX	41	BATTERY
16	BUSH	42	CONNECT PLATE
17	OUTPUT SHAFT	43	LOCK BUTTON
18	INNER TOOTH RING	44	LOCK SPRING
19	Ⅱ PLANET GEAR	45	BATTERY PACK HOUSING
20	PLANET BRACKET	46	CHARGE BASE
21	Ⅰ PLANET GEAR	47	ADAPTER
22	GEAR BOX COVER	101	BATTERIES PACK
23	SCREW	102	GEAR BOX ASSEMBLE
24	MOTOR GEAR	888	HOUSING ASSEMBLE

BM20110221

BauMaster